

Notebooks, Netbooks and UMPCs

Green Text with Light Green Background indicates the adapter tip is included with Product.

Red Text with Clear Background indicates the adapter tip is sold separately.

N/A indicates that the adapter is not available or the Product is not compatible.

Acer Aspire One

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|---|--------|--------|---------|--------|------------------------|
| Aspire One A110L, A110X | PA-N12 | PA-N12 | PA-N12 | PA-N12 | |
| Aspire One A150, A150L, A150X, A150X-3G | PA-N12 | PA-N12 | PA-N12 | PA-N12 | |
| Aspire One D150 | PA-N12 | PA-N12 | PA-N12 | PA-N12 | |

Acer Aspire

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|---|--------|--------|---------|--------|------------------------|
| 2000, 2010, 2020, 2200 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| 3000, 3500, 3600, 3610, 3624, 3630, 3680 Series | PA-L47 | PA-L47 | PA-L47 | PA-L47 | |
| 3020, 3025, 3040, 3620, 3690 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| 5000, 5020, 5030, 5040, 5100, 5110, 5500, 5600, 5610, 5630, 5680, 5920, 7000, 7100 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| 5010, 5012, 5014, 9800, 9805, 9810 Series | PA-L47 | PA-L47 | PA-L47 | PA-L47 | |
| 9100, 9300, 9410, 9420, 9500 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |

Acer Ferrari

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|---|--------|--------|---------|--------|------------------------|
| 1000, 1004, 3000, 3200, 3400, 4000, 5000 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |

Acer TravelMate

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|---|--------|--------|---------|--------|------------------------|
| A550, A551, Alpha 550, Alpha 551 Series | PA-L5D | PA-L5D | PA-L5D | PA-L5D | |
| C100, C110, C200, C210, C300, C310 Series | PA-L47 | PA-L47 | PA-L47 | PA-L47 | |
| 200, 210, 212, 213, 220, 225, 230, 233, 260, 270, 272, 273, 280, 283 Series | PA-L5D | PA-L5D | PA-L5D | PA-L5D | |
| 240, 243, 244, 250, 252, 253, 290, 291, 292, 293 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| 530, 531, 533, 534, 535, 536 Series | PA-L5D | PA-L5D | PA-L5D | PA-L5D | |
| 540, 541, 542, 543 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| 800, 803, 810, 811, 812, 813, 814, 820, 830, 831, 850, 853, 854, 860 Series | PA-L5D | PA-L5D | PA-L5D | PA-L5D | |
| 720, 722, 730, 732, 735, 739, 740, 800, 801, 802, 803, 804 Series | PA-L5D | PA-L5D | PA-L5D | PA-L5D | |
| 2000, 2100, 2200, 2500, 2600, 2700 Series | PA-L5D | PA-L5D | PA-L5D | PA-L5D | |
| 2300, 2310, 2350, 2400, 2420, 2450, 2480 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| 3000, 3200, 3210, 3220, 3230, 3260 Series | PA-L47 | PA-L47 | PA-L47 | PA-L47 | |
| 5100, 5110, 5300, 5600, 5610, 5612, 6000, 6100, 6410, 6460, 6592 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| 7000, 7100, 7300, 8000, 8100, 8200, 8204, 8205, 8210, 8215, 8216 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |

Apple

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|------------------------------------|--------|--------|---------|--------|--|
| PowerBook: 1400, 2400, 3400 Series | n/a | PA-N03 | PA-N03 | PA-N03 | Input adapter not available to charge MP3750 |
| PowerBook: G3 Series | n/a | PA-N03 | PA-N03 | n/a | Input adapter not available to charge MP3750 |
| PowerBook G4, iBook G4 | n/a | n/a | n/a | n/a | Adapter not available |
| MacBook, MacBook Pro | n/a | PA-MAG | PA-MAG | PA-MAG | Input adapter not available to charge MP3750 |

ASUS Eee PC

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|--------------------------------------|--------|--------|---------|--------|--|
| Eee PC 700, 900 Series | PA-L47 | PA-L47 | PA-L47 | PA-L47 | |
| Eee PC 1000HA, 1000HD Series | PA-L47 | PA-L47 | PA-L47 | PA-L47 | |
| Eee PC 1005, 1008, 1101, 1201 Series | n/a | PA-L23 | PA-L23 | PA-L23 | Input adapter not available to charge MP3750 |

ASUS

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|--|--------|--------|---------|--------|------------------------|
| A6, A6JA, A6JC, A6K, A6KM, A6KT, A6R, A6V, A6VA, A6Vc, A6VM, A7S, A8, A8F Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| F3, F3P, F8, F9, F9F Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| G1 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| M2000, M2000N, M6000N, M6700N, M6800N, M6B00N Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| M6N, M6V, M6VA, M9V, M50, M51, M70 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| R1E, S6F, U3, U5A, U5F, U6E, U6S Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| V1, V1J, V2, V6, VX2, VX3 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| W3000, W3, W3N, W3V, W5A, W5Ae, W5F, W5V, W7, W7J, Z35L Series | n/a | PA-L5F | PA-L5F | PA-L5F | |

Dell Adamo

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|----------|--------|--------|---------|--------|------------------------|
| Adamo 13 | n/a | PA-L5F | PA-L5F | PA-L5F | |

Dell Inspiron

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|---|--------|--------|---------|--------|--|
| 14, 15, 17 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| 1100 Series | n/a | PA-N07 | PA-N07 | PA-N07 | Input adapter not available to charge MP3750 |
| 1150, 1318, 1420 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| 1501, 1505, 1520, 1521, 1525, 1526, 1545 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| 1720, 1721 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| 4000, 4100, 4150, 4200, 5000, 5100, 5150 Series | n/a | PA-N07 | PA-N07 | PA-N07 | Input adapter not available to charge MP3750 |
| 6000, 6400 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| 7500, 8000, 8100, 8200 Series | n/a | PA-N07 | PA-N07 | PA-N07 | Input adapter not available to charge MP3750 |
| 8500, 8600, 9100, 9200, 9300, 9400 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| 300m, 500m, 600m, 630m, 640m, 700m, 710m Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| E1405, E1505, E1705 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| Mini 9, Mini 10, Mini 12 | n/a | PA-N12 | PA-N12 | PA-N12 | |

| Dell Latitude | | | | | |
|---|--------|--------|---------|--------|--|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| 2100, 2100n Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| CP, Cpi, CPi, CS, CPx Series | n/a | PA-N07 | PA-N07 | PA-N07 | Input adapter not available to charge MP3750 |
| D400, D410, D420, D430 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| D500, D505, D510, D520, D530, D531, D560 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| D600, D610, D620, D630, D631 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| D800, D810, D820, D830 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| E4200, E4300, E5400, E5500, E6400, E6500 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| XT, XT2 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| X1, X300 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |

| Dell Precision | | | | | |
|----------------------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| M20 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| M60, M65, M70 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| M2300, M2400, M4300 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |

| Dell Studio | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| Studio 14z, 15, 1535, 1536, 1537, 1555 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| Studio XPS 13, Studio XPS 1340 | n/a | PA-N11 | PA-N11 | PA-N11 | |
| Studio XPS 16 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |

| Dell Vostro | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| A90, A860 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| 1000, 1220, 1310, 1320, 1400, 1500, 1510, 1520, 1700 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| 2510 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |

| Dell XPS | | | | | |
|----------------------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| M140 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |
| M1210, M1330, M1530 Series | n/a | PA-N11 | PA-N11 | PA-N11 | |

| Fujitsu LifeBook | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| A4170, A4177, A4178, A4187, A4190, A6010, A6020, A6025, A6030, A6110, A6120, A6210, A6210, A6220, A6230 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| B2130, B2131, B2175, B2545, B2562, B2566, B2610, B2620, B2630 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| B3000, B3000D, B3010D, B3020, B3020D Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| B6110D, B6210, B6220, B6230 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| C2010, C2110, C2111, C2210, C2310, C2320, C2330 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| C-6581, C-6591, C-6611, C-6631, C-6651, C-7631, C-7651, C-7661 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| E6624, E6634, E6644, E6654, E6664, E6666, E7010, E7110 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| E8010, E8010D, E8020, E8020D, E8110, E8210, E8310, E8410 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| M2010 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| N3000, N3010, N3511, N3520, N3530 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| N5000, N5010, N6010, N6110, N6210, N6410, N6420 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| P1000, P1032, P1035, P1120, P1510, P1510D, P1610, P1620, P1630 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| P5000, P5010, P5010D, P5020, P5020D, P7010, P7010D Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| P7120, P7120D, P7230, P7230D, P7230P, P8010, P8020 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| Q2010 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| S2010, S2020, S2110 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| S2210 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| S6010, S6110, S6120, S6120D, S6210, S6220, S6231, S6240 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| S6310, S6311, S6410, S6510, S6520 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| S7000, S7000D, S7010, S7010D, S7020, S7020B, S7020D, S7020E, S7021, S7025, S7110, S7111, S7210, S7211, S7220 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| T1010, T4010, T4010D, T4020, T4020D Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| T4210, T4215, T4220, T5010, T5010A, T5010W Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| U810, U820 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| V1010, V1020, V1030, V1040 Series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |

| Fujitsu Stylistic | | | | | |
|--|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| ST4110, ST4110P, ST4120, ST4120P, ST4121 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| ST5000, ST5000D, ST5010, ST5010D, ST5011, ST5011D, ST5020, ST5020D, ST5021, ST5021D, ST5022, ST5022D, ST5030, ST5030D, ST5031, ST5031D, ST5032, ST5032D, ST5111, ST5112, ST6012 Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |
| T2010, T2020, T3010, T3010D Series | PA-L65 | PA-L65 | PA-L65 | PA-L65 | |

Gateway

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|---|--------|--------|---------|--------|------------------------|
| 400, 400L, 400S, 400SD4, 400SP, 400VFX, 400X, 400XL, 450, 450E, 450RGH, 450ROG, 450S, 450SP, 450SX4, 450X, 450XL Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| 3000, 3018, 3018GZ, 3040, 3040GZ, 3500, 3520, 3520GZ, 3522, 3522GZ, 3525GB, 3525GZ, 3545, 3545GZ, 3550, 3550GH, 3550GZ, 3610GZ Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| 4000, 4010, 4012, 4012GZ, 4014, 4014GB, 4016, 4024, 4024GZ, 4025, 4025GZ, 4026, 4026GZ, 4028, 4028GZ, 4028JP, 4030, 4030GH, 4030GZ Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| 4520, 4520GZ, 4525, 4525GZ, 4528, 4528MX, 4530, 4530GH, 4530GZ, 4532, 4534, 4535, 4535GZ, 4536, 4536GZ, 4538, 4538GZ, 4540, 4540GZ, 4541, 4541BZ, 4542, 4542GP, 4543, 4543BZ Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| 6000, 6010, 6010GZ, 6018, 6018GH, 6018GZ, 6018GX, 6020, 6020GZ, 6021, 6021GH, 6021GZ, 6022, 6022GZ, 6023, 6023GP, 6510, 6510GZ, 6518, 6518GZ, 6520, 6520GZ, 6525, 6525GP, 6530, 6531, 6531GZ Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| 7000, 7110, 7110GX, 7210, 7210GX, 7215, 7215GX, 7300, 7305, 7305GZ, 7305GX, 7310, 7310MX, 7312, 7312MX, 7320, 7320GZ, 7322, 7322GZ, 7324, 7324GZ, 7325, 7325GZ, 7326, 7326GZ, 7330, 7330GH, 7330GZ, 7400, 7405, 7405GH, 7405GX, 7410, 7410GX, 7415, 7415GX, 7422, 7422GX, 7422GZ, 7426, 7426GX, 7430, 7430JP, 7500, 7508, 7508GX, 7510, 7510GX Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| CX200, CX200S, CX200X, CX210, CX210S, CX210X, CX2600, CX2608, CX2610, CX2615, CX2618, CX2619, CX2620, CX2620H, CX2700, CX2720, CX2724, CX2724H, CX2726, CX2728 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| M210, M210CS, M210E, M210S, M210XL, M250, M250E, M250ES, M250A, M250B, M250G, M250GS, M250S, M250X, M255-E, M255-E SB, M255 G, M280, M280E, M280Eb, M280GS, M285-E, M285-E SB, M285 G Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| M305, M305CRV, M320, M320CS, M320E, M320S, M320X, M320XL, M325, M325X, M360, M360S, M360SB, M360SE, M360X, M360XL, M360A, M360B, M360C Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| M405, M460A, M460B, M460E, M460E Plus, M460ES, M460S, M460SX, M460S-QS, M460SX Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| M500, M500B1, M505, M505B2 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| ML3000, ML3704, ML3706, ML6000, ML6219, ML6701, ML6703, ML6704, ML6704H Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| MT3000, MT3400, MT3418, MT3700, MT3705, MT3707 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| MT6400, MT6451, MT6452, MT6456, MT6700, MT6704, MT6704H, MT6705, MT6707, MT6800, MT6821, MT6828, MT6828H Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| MX3000, MX3042, MX3044, MX3044H, MX3200, MX3210, MX3212, MX3215, MX3225, MX3228, MX3228H, MX3258, MX3258H, MX3558, MX3558H, MX3560, MX3560H, MX3562, MX3563, MX3563H, MX3600, MX3610 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| MX6000, MX6025, MX6025H, MX6027, MX6027H, MX6028, MX6030, MX6121, MX6123, MX6124, MX6124H, MX6128, MX6135, MX6420, MX6421, MX6423, MX6424, MX6424H, MX6425, MX6428, MX6430, MX6433, MX6433H, MX6436, MX6437, MX6438, MX6440, MX6440B, MX6440H, MX6441, MX6442, MX6450, MX6453, MX6455 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| MX6625, MX6627, MX6627H, MX6629, MX6629H, MX6631, MX6633, MX6633H, MX6640, MX6640B, MX6641, MX6641H, MX6650, MX6650H, MX6708, MX6708H, MX6710, MX6750, MX6912, MX6951, MX6951H, MX6958, MX6960 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| MX8500, MX8520, MX8523, MX8525, MX8528, MX8530, MX8554B, MX8556F, MX8700, MX8710, MX8711 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| NX100X, NX200, NX200S, NX200X, NX210, NX250, NX250X, NX260, NX260X, NX500, NX500S, NX500X, NX510, NX510S, NX510X, NX550, NX550X, NX550XL, NX560, NX560X, NX560XL, NX570, NX570QS, NX570X, NX570XL Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| NX860, NX860X, NX860XL Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| S-7200, S-7200C, S-7200N Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| X2620H Series | n/a | PA-L5F | PA-L5F | PA-L5F | |

Gateway Solo

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|---|--------|--------|---------|--------|------------------------|
| 1100, 1150, 1200, 1400, 1450 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| 2000, 2100, 2150, 2200, 2300, 2300LS, 2300XL, 2500, 2500LS, 2500SE, 2500XL, 2550, 2551 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| 5000, 5100, 5100XL, 5150LS, 5150SE, 5150XL, 5300, 5300CS, 5300L, 5300LS, 5350 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| 9100, 9100LS, 9100SE, 9100XL, 9150, 9300, 9300CX, 9300VE, 9300XL Series | n/a | PA-L5F | PA-L5F | PA-L5F | |

| HP | | | | | |
|---------------------------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| Mini 110, Mini 700 | n/a | PA-L42 | PA-L42 | PA-L42 | |
| Mini 311 | n/a | PA-N01 | PA-N01 | PA-N01 | |
| Mini 1000, Mini 1033, Mini 1100 | n/a | PA-L42 | PA-L42 | PA-L42 | |
| 2133 Mini-Note PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| Mini 2140 Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| 2533r Mobile Thin Client | n/a | PA-N10 | PA-N10 | PA-N10 | |
| S10, S30, S50 Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| G50, G60, G70 | n/a | PA-N10 | PA-N10 | PA-N10 | |
| G3000, G5000, G6000, G7000 | n/a | PA-N01 | PA-N01 | PA-N01 | |

| HP EliteBook | | | | | |
|---------------------------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| 2530p, 2710p, 2730p Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| 6930p, 8530p Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |

| HP / Compaq | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| 2230s, 2510p, 2710p Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| 6510b, 6515b, 6530b, 6535b, 6710b, 6715b, 6720s | n/a | PA-N10 | PA-N10 | PA-N10 | |
| 6720t Mobile Thin Client | n/a | PA-N10 | PA-N10 | PA-N10 | |
| 6730b, 6730s, 6735b, 6735s, 6820s, 6830s, 6910p Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| 8510p, 8710p Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| Mini 2140 Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| NC2400, NC4010, NC4200, NC4400 Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| NC6120, NC6140, NC6220, NC6230, NC6320, NC6400 Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| NC8430 Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| NX6110, NX6115, NX6325, NX7300, NX7400, NX9420 Notebook PC | n/a | PA-N10 | PA-N10 | PA-N10 | |
| TC4200, TC4400 Tablet PC | n/a | PA-N10 | PA-N10 | PA-N10 | |

| HP / Compaq Pavilion | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| DV1000, DV2000, DV4000, DV5000z, DV6000, DV8000 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| DV9000, DV9500 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| DV3, DV4, DV4t, DV4z, DV5, DV6, DV7 Series | n/a | PA-N10 | PA-N10 | PA-N10 | |
| TX1000, TX2000 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| ZE2000, ZE4000, ZE4100, ZE4200, ZE4300, ZE4400, ZE4500, ZE4600, ZE4700, ZE4800, ZE4900, ZE5000 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| ZT3000, ZT3100, ZT3200, ZT3300, ZT3400 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| ZV6000, ZV6100, ZV6200 Series | n/a | n/a | n/a | n/a | Adapter not available |

| HP / Compaq Presario | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| 2100, 2200, 2500 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| C500T Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| CQ50-115NR | n/a | PA-N10 | PA-N10 | PA-N10 | |
| F730, F750 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| M2000 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| R4000, R4100, R4200 Series | n/a | n/a | n/a | n/a | Adapter not available |
| V1000, V2000, V3000, V4000, V5000, V6000 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| X1000 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| X1200, X1300, X1400, X1500 Series | n/a | PA-N01 | PA-N01 | PA-N01 | |
| X6000 | n/a | n/a | n/a | n/a | Adapter not available |

| HTC | | | | | |
|-------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| Shift X9500 | PA-L5D | PA-L5D | PA-L5D | PA-L5D | |

| Kohjinsha | | | | | |
|------------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| SA series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| SH series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| SR series | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |

| Lenovo IdeaPad | | | | | |
|-----------------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| S9, S9e Series | n/a | PA-S5F | PA-S5F | PA-S5F | |
| S10, S10e Series | n/a | PA-S5F | PA-S5F | PA-S5F | |
| S10-2 Series | n/a | PA-S5F | PA-S5F | PA-S5F | |

| Lenovo / IBM ThinkPad | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| A20m, A20p, A21e, A21m, A21p, A22e, A22m, A22p, A30, A30p, A31, A31p Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| R30, R31, R32, R40, R40e, R50, R50e, R50p, R51, R51e, R52 Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| R60, R60e, R61, R61i, R61e Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| R400, R500 Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| SL300, SL400, SL500 Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| T20, T21, T22, T23, T30, T40, T40p, T41, T41p, T42, T42p, T43, T43p Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| T60, T60p, T61 Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| T400, T500, W500 Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| X20, X21, X22, X23, X24, X30, X31, X40, X41, X41 Tablet Series | n/a | PA-L5F | PA-L5F | PA-L5F | |
| X60, X60s, X61, X61s, X61s Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| X200, X300 Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| Z60, Z60m, Z60t, Z61p Series | n/a | PA-N09 | PA-N09 | PA-N09 | |

| Lenovo / IBM 3000 | | | | | |
|--------------------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| C100, C200 Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| N100, N200 Series | n/a | PA-N09 | PA-N09 | PA-N09 | |
| V100, V200 Series | n/a | PA-N09 | PA-N09 | PA-N09 | |

| MSI | | | | | |
|------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| Wind U100 | n/a | PA-L5F | PA-L5F | PA-L5F | |
| CX600 | n/a | PA-L5F | PA-L5F | PA-L5F | |

| Neoware | | | | | |
|----------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| M100 | n/a | PA-L5F | PA-L5F | PA-L5F | |

| OOO | | | | | |
|------------|--------|--------|---------|--------|--|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| Model 02 | PA-CLA | PA-CLA | PA-CLA | PA-CLA | Input adapter not available to charge MP3750 |

Panasonic Toughbook

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|--|--------|--------|---------|--------|------------------------|
| CF-08, CF-18, CF-19 | n/a | PA-S5F | PA-S5F | PA-S5F | |
| CF-R3, CF-R4, CF-R4, CF-R5, CF-R6, CF-R7 | n/a | PA-S5F | PA-S5F | PA-S5F | |
| CF-T1, CF-T2, CF-T4, CF-T5, CF-T7 | n/a | PA-S5F | PA-S5F | PA-S5F | |
| CF-W2, CF-W4, CF-W5, CF-W7 | n/a | PA-S5F | PA-S5F | PA-S5F | |
| CF-Y2, CF-Y4, CF-Y5, CF-Y7 | n/a | PA-S5F | PA-S5F | PA-S5F | |

Samsung

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|--------------------------|--------|--------|---------|--------|---|
| NC10, NC20 mini notebook | n/a | PA-L55 | PA-L55 | PA-L55 | Input Adapter PA-L55F required to charge MP3750 |
| N110 Series | n/a | PA-L55 | PA-L55 | PA-L55 | Input Adapter PA-L55F required to charge MP3750 |
| NP-P200 | n/a | PA-L55 | PA-L55 | PA-L55 | Input Adapter PA-L55F required to charge MP3750 |
| P460, P560 Series | n/a | PA-L55 | PA-L55 | PA-L55 | Input Adapter PA-L55F required to charge MP3750 |
| Q1, Q1EX, Q1U Series | PA-L55 | PA-L55 | PA-L55 | PA-L55 | Input Adapter PA-L55F required to charge MP3750 |
| Q310 Series | n/a | PA-L55 | PA-L55 | PA-L55 | Input Adapter PA-L55F required to charge MP3750 |
| R610 Series | n/a | PA-L55 | PA-L55 | PA-L55 | Input Adapter PA-L55F required to charge MP3750 |
| X360, X460 Series | n/a | PA-L55 | PA-L55 | PA-L55 | Input Adapter PA-L55F required to charge MP3750 |

Sony Vaio

| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
|---|--------|--------|---------|--------|---|
| PCG-700, PCG-800 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| LX180P | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-AR290G | n/a | n/a | n/a | n/a | Laptop power requirement is too high, not recommended |
| VGN-BX670, VGN-BX675 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-C140, VGN-C150, VGN-C190, VGN-C210, VGN-C220, VGN-C240, VGN-C250, VGN-C260, VGN-C290 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-CR240, VGN-290, VGN-CR305, VGN-CR390, VGN-CR490, VGN-CR590, VGN-CS190, VGN-CS290 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FE550, VGN-FE570, VGN-FE590, VGN-FE600, VGN-FE650, VGN-FE660, VGN-FE670, VGN-FE680, VGN-FE690 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FE770, VGN-FE780, VGN-FE790, VGN-FE855, VGN-FE870, VGN-FE880, VGN-FE890 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FS500, VGN-FS520, VGN-FS530, VGN-FS540, VGN-FS550, VGN-FS550, VGN-FS570 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FS620, VGN-FS630, VGN-FS640, VGN-FS650, VGN-FS660, VGN-FS670, VGN-FS680, VGN-FS690 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FS710, VGN-FS720, VGN-FS730, VGN-FS740, VGN-FS750, VGN-FS760, VGN-FS770, VGN-FS780, VGN-FS790 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FS810, VGN-FS830, VGN-FS840, VGN-FS850, VGN-FS875, VGN-FS900 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FS920, VGN-FS940, VGN-FS950, VGN-FS960, VGN-FS970, VGN-FS980, VGN-FS990 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FW290 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-FZ130, VGN-FZ140, VGN-FZ150, VGN-FZ160, VGN-FZ180, VGN-FZ190 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-N110, VGN-N120, VGN-N130, VGN-N150, VGN-N160, VGN-N170, VGN-N220, VGN-N230, VGN-N250, VGN-N270, VGN-N320, VGN-N330, VGN-N370 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-NS190, VGN-NS235, VGN-NS290 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-P530H, VGN-P588E, VGN-P598E Series | PA-L47 | PA-L47 | PA-L47 | PA-L47 | |
| VGN-S380, VGN-S430, VGN-S460, VGN-S470, VGN-S480, VGN-S550, VGN-S560, VGN-S570, VGN-S580, VGN-S660 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-SR290 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-SZ210, VGN-SZ220, VGN-SZ230, VGN-SZ240, VGN-SZ250, VGN-SZ260, VGN-SZ270, VGN-SZ280 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-SZ320, VGN-SZ330, VGN-SZ340, VGN-SZ360, VGN-SZ370, VGN-SZ380, VGN-SZ390 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-SZ430, VGN-SZ440, VGN-SZ450, VGN-SZ460, VGN-SZ470, VGN-SZ480, VGN-SZ491, VGN-SZ640, VGN-SZ650, VGN-SZ670 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-SZ691, VGN-SZ750, VGN-SZ770, VGN-SZ791 Series | n/a | PA-L65 | PA-L65 | PA-L65 | |
| VGN-TXN25NB Series | n/a | PA-L65 | PA-L65 | PA-L65 | |

| Toshiba Mini Notebook | | | | | |
|------------------------|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| NB205-N2xx, NB205-N3xx | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |
| NB305-N3xx, NB305-N4xx | PA-L5F | PA-L5F | PA-L5F | PA-L5F | |

| Toshiba Portege | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| 2000, 2010, 3500, 3505, 4000, 4005, 4010 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| 7000CT, 7010CT, 7020CT, 7140CT, 7200CT/Cle, 7220Cle Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| M100, M200, M205, M300, M400, M405, M700, M705, M750 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| R100, R200, R400, R500, S100 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |

| Toshiba Qosmio | | | | | |
|---------------------------|--------|--------|---------|--------|---|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| E15, F15, F25, F45 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| G15, G25, G35, G45 Series | n/a | n/a | n/a | n/a | Laptop power requirement is too high, not recommended |
| X305 | n/a | n/a | n/a | n/a | Laptop power requirement is too high, not recommended |

| Toshiba Satellite | | | | | |
|---|--------|--------|---------|--------|---|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| 1400, 1405, 1410, 1415, 1800, 1805 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| 2060, 2100, 2140XCDS, 2180CDT, 2210CDT/XCDS, 2230, 2250, 2400, 2405, 2410, 2415, 2505CDS, 2510, 2520, 2530, 2540, 2550, 2590CDT/CDS/CDT/XDVD, 2610, 2615DVD, 2650, 2655XDVD, 2670, 2710, 2740, 2750, 2770, 2800/2805 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| 3000, 3005 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| 4000CDS/CDT, 4005CDS/CDT, 4010CDS/CDT, 4015CDS/CDT, 4020CDT, 4025CDT, 4030CDT, 4060, 4070, 4080CDT, 4090XDVD, 4100XDVD Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| 5000, 5005, 5105, 5200, 5205 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| A10, A15, A30, A35, A50, A55, A60, A65, A70, A75, A80, A85 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| A20, A25, A40, A45 Series | n/a | n/a | n/a | n/a | Laptop power requirement is too high, not recommended |
| A100, A105, A110, A130, A135 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| A200, A205, A215 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| L10, L15, L20, L25, L35, L45 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| M20, M30, M35, M40, M45, M50, M55, M60, M65 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| M100, M105, M110, M115 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| M200, M205 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| P10, P15, P30, P35 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| P100, P105 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| P100-ST9xxx, P105-S921, P105-S9xxx Series | n/a | n/a | n/a | n/a | Laptop power requirement is too high, not recommended |
| P200, P205 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| R10, R15, R20, R25 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| U200, U205 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| U300, U305 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |

| Toshiba Satellite Pro | | | | | |
|--|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| 430, 440, 450, 460, 470, 480, 490 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| 4280ZDVD, 4220, 4260DVD, 4280XDVD, 4300, 4600 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| 6000, 6100 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| A200, A210 Series | n/a | PA-L63 | PA-L63 | PA-L63 | |
| M10, M15 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| S300, S300M Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |

| Toshiba Tecra | | | | | |
|---|--------|--------|---------|--------|------------------------|
| Model | MP3300 | MP3450 | MP3450i | MP3750 | Additional Information |
| 8000, 8100, 8200, 9000, 9100 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| A1, A2, A3, A4, A5, A8, A9, A10 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| M1, M2, M2V, M3, M4, M5, M6, M7, M8, M9, M10 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| R10, S1, S2, S3 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |
| TE2000, TE2100, TE2300 Series | PA-L63 | PA-L63 | PA-L63 | PA-L63 | |