

eBooks, Photo Frames, Field Recorders and More

Green Text with Light Green Background indicates the adapter tip is included with Product.

Red Text with Clear Background indicates the adapter tip is sold separately.

N/A indicates that the adapter is not available or the Product is not compatible.

* MP3450i requires PA-L34 or PA-S34 (not included in original package) to use UA-xxx adapter tips *

Amazon

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Kindle	PA-L23	PA-L23	PA-L23	UA-L23	UA-L23
Kindle 2	UA-U11	UA-U11	UA-U11	UA-U11	UA-U11

Barnes & Noble

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Nook	UA-U11	UA-U11	UA-U11	UA-U11	UA-U11

ClearWire

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Motorola Modem: RSU-2510-SV	PA-L34	PA-L34	PA-L34	n/a	n/a

JBL

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Onstage II	PA-L5F	PA-L5F	PA-L5F	n/a	n/a

Kodak

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Photo Frame Dock	PA-L40	PA-L40	PA-L40	UA-L40	UA-L40
Photo Frame Dock 2	PA-L40	PA-L40	PA-L40	UA-L40	UA-L40

Sonnet

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Fusion F2 (Portable Storage Solution)	PA-L34	PA-L34	PA-L34	PA-L34	PA-L34

Sony

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Sony Reader	PA-L40	PA-L40	PA-L40	UA-L40	UA-L40
DVDirect DVD Recorder: VRD-MC5	PA-L55	PA-L55	PA-L55	PA-L55/PA-L55F	PA-L55/PA-L55F

VIVLED

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Light: coolLED-40	PA-L5D	PA-L5D	PA-L5D	n/a	n/a
Light: dayLED-40, warmLED-40	PA-L5D	PA-L5D	PA-L5D	n/a	n/a
Light: warmLED-40	PA-L5D	PA-L5D	PA-L5D	n/a	n/a

Zoom

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Field Recorder: H4-Handy Recorder	PA-L5F	PA-L5F	PA-L5F	n/a	n/a
Field Recorder: PFX-9003 Palmtop Effects Processor	PA-L34	PA-L34	PA-L34	n/a	n/a
Field Recorder: PS-04 Personal Multi-Track Studio	PA-L34	PA-L34	PA-L34	n/a	n/a

Zylight

Model	MP3300	MP3450	MP3450i	MP3700	MP3750
Portable Light: Z50	PA-L5D	PA-L5D	PA-L5D	n/a	n/a
Portable Light: Z90	n/a	n/a	n/a	n/a	n/a